Changing the Battery in the Digital Multi-Day Max/Min Thermometer

Field Guide

Task

Change the battery in the digital Max/Min Thermometer.

What You Need

- ☐ A new AA-size battery
- ☐ A small Phillips head screwdriver

In the Field

- 1. The battery is in the battery compartment in the lower section of the instrument casing.
- 2. Remove the two little screws located at the upper corners of the compartment cover and lift off the cover.
- 3. Change the battery, taking care to ensure correct polarity (negative end of battery contacting the spring).
- 4. Replace the compartment cover and secure with the two screws.





